

# Installation Instructions

## PEX Supply Tubes



### Installation

- Ensure a proper seal
- Make clean cut on riser
- Be sure riser is squared and flush fitting in supply stop
- Pipe dope, compounds and sealants should not be used for installation because they have been known to cause leakage
- Hand tighten - DO NOT OVERTIGHTEN
- Metal nuts tighten 1 additional turn with wrench
- Plastic nuts tighten to additional turn with wrench

Wolseley's North American operating companies assume no responsibility for failure due to improper installation.

### Model Numbers

PF3812LR	3/8" x 12"	Lavatory Riser
PF3820LR	3/8" x 20"	Lavatory Riser
PF3830LR	3/8" x 30"	Lavatory Riser
PF3836LR	3/8" x 36"	Lavatory Riser
PF3812CRX	3/8" x 12"	Closet Riser
PF3820CRX	3/8" x 20"	Closet Riser