## **SPEAKMAN URINAL FLUSH VALVE** Installation, Maintenance & Operation Instructions <u>SUV-2000 Urinal Flush Valve Series</u>

#### **DESCRIPTION**

The <u>SUV-2000 Urinal Flush Valve Series</u>, combines a battery operated electronic Flush Valve with a sweat solder kit & stop, vacuum breaker and spud coupling. The Flush Valve has an Infrared Sensor that controls a Solenoid Valve powered by a set of Batteries. There is also a side push button for Maintenance purposes in case a manual activation is needed. The push button has an optional vandal resistant cover for high potential vandal installations. The valve meets ASSE 1037 and ASME A112.19.2-2003

#### **SPECIFICATIONS**

| PRODUCT                      | Urinal Flush Valve                                       |
|------------------------------|----------------------------------------------------------|
| Casing Material              | Chrome plated brass casting                              |
| Power Supply                 | DC6V (CR-P2 Lithium battery)                             |
| Power consumption            | 3W or less                                               |
| Sensing distance             | 6"-20" -Factory setting 8"-10"                           |
| Flushing time                | 0.5, 0.7, 1.0, 1.25, 1.5, 2.0, 2.5, 3.0 sec (adjustable) |
| Detection Time               | 7 seconds                                                |
| Flush Delay                  | 1 second                                                 |
| Applicable water pressure    | 1-7 Kgf/ cm2 (15 PSI ~ 100 PSI)                          |
| Water outlet Pipe bore       | 3/4"                                                     |
| Water inlet pipe diameter    | 3/4"                                                     |
| Applicable room temperature  | 4C-45C                                                   |
| Applicable water temperature | 4C-65C (no icing up)                                     |
| Factory Settings             | 1.0 GPF                                                  |


#### **MODELS** available:

| SUV-2000<br>SUV-2110 | Urinal valve body replacement to existing Sloan valve (no trim)<br>Urinal valve, ¾" sweat solder & stop, ¾" x 9" vacuum breaker + spud coupling |                                                                                                                                                                                                                |
|----------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| SUV-2130<br>SUV-2210 |                                                                                                                                                 | sweat solder & stop, 1 <sup>1</sup> / <sub>2</sub> " x 9" vacuum breaker + spud coupling<br>sweat solder & stop, <sup>3</sup> / <sub>4</sub> " x 9" vacuum breaker + spud coupling                             |
| SUV-2230             | Urinal valve, 1"                                                                                                                                | sweat solder & stop, 1 <sup>1</sup> / <sub>2</sub> " x 9" vacuum breaker + spud coupling                                                                                                                       |
| <u>SUV-2XY0</u>      | Х                                                                                                                                               | <ul> <li>= (1) <sup>3</sup>/<sub>4</sub>" sweat solder kit &amp; stop</li> <li>= (2) 1" sweat solder kit &amp; stop</li> <li>= (1) <sup>3</sup>/<sub>4</sub>" x 9" vacuum breaker and spud coupling</li> </ul> |
|                      | Y                                                                                                                                               | $= (3) 1\frac{1}{2}$ " x 9" vacuum breaker and spud coupling                                                                                                                                                   |

#### SPEAKMAN

PO Box 191 Wilmington, DE 19899 Phone: 800-537-2107 Fax: 800-977-2747 Visit us on the web at www.speakmancompany.com

#### Stand Installation




#### ■ How to use



- 1. A continuous invisible light beam is emitted from the Valve sensor. As the user enters the beam's effective range of 6" to 20" more than 7 seconds, the output circuit continues in a "hold" mode for as long as the user remains within the effective range of the sensor.
- 2. When user leaves the sensing area, the unit automatically flushes the toilet.

SPEAKMAN PO Box 191 Wilmington, DE 19899 Phone: 800-537-2107 Fax: 800-977-2747 Visit us on the web at www.speakmancompany.com

Cautions



- 1. Keep the sensor lens clean all the time, to avoid dirt or stain deposit to avoid poor sensing.
- 2. Do not press or put cigarette butts or other objects on the casing.
- 3. Do not spray water or wash the casing with strong acid, which may result in short-circuit of the electronic board inside, or cause corrosion on casing. WIPE off any stain with a wet soft cloth.


#### Installation and cautions

1. Check water supply



- a. Remove extraneous matter from the water pipe to avoid obstruction.
- b. Make sure to turn off water supply before installation.

#### 2. Install water stop valve




- a. Solder Threaded Adapter onto water inlet pipe coming from the wall (if needed).
- b. Insert the Supply Flange and the Cover Tube over the Adapter. Tighten the set screw.
- c. Connect Control Stop to inlet threaded pipe adapter.
- d. Connect Stop Cap to control stop valve assembly.

#### **SPEAKMAN**<sup>°</sup>


PO Box 191 Wilmington, DE 19899 Phone: 800-537-2107 Fax: 800-977-2747 Visit us on the web at www.speakmancompany.com

#### 3. Install Vacuum Breaker Tube



- a. Insert spud coupling, PC slip gasket, rubber gasket and spud flange through vacuum breaker tube.
- b. Insert vacuum breaker tube into water inlet of water closet bowl.
- c. Tighten vacuum breaker to valve body.

#### 4. Install Flush Valve body




- a. Wet O-ring seal on Tailpiece Assembly inlet with water to lubricate.
- b. Insert Tailpiece Assembly to Control Stop Assembly.
- c. Join Stop Coupling to Control Stop Assembly adjusting the threaded sleeve of Adjuster piece for desired length.
- d. Align Flush Valve body with Vacuum Breaker Tube.
- e. Tighten Connection Nut.

### SPEAKMAN

PO Box 191 Wilmington, DE 19899 Phone: 800-537-2107 Fax: 800-977-2747 Visit us on the web at www.speakmancompany.com

- 5. <u>Rotate the Flush Valve</u> for Left hand installation
- Locking Ring-Setting Screw Cover Electronics case Holding Screw Sensor Lens Left Hand Mounting Right Hand Mounting
- a. The Sensor Lens comes positioned for Right Hand Mounting.
- b. For Left Hand installation, take the Cover off, and take out the 2 Holding Screws.
- c. Rotate the Electronics Case 180°
- d. Tighten back the 2 Screws and the Sensor Lens is repositioned now for Left Hand Mounting.
  - 6. <u>Adjust distance</u> <u>to wall pipe</u>




- e. Regular distance between water stop valve and water inlet main unit is 4 3/4" (121mm).
- f. Range of adjustable distance from nominal: extend or shorten with 1/2"(12.5mm).
- g. Rotate the threaded Adapter sleeve onto the Tailpiece to position the Stop Coupling Nut.

#### SPEAKMAN

PO Box 191 Wilmington, DE 19899 Phone: 800-537-2107 Fax: 800-977-2747 Visit us on the web at www.speakmancompany.com

7. Install battery -One 6-volt lithium. Panasonic CR-P2 or Duracell 223



- a. Unscrew the set screw from the side of the locking ring with allen wrench provided.
- b. Remove locking ring, cover and battery seal in sequential order.
- c. Insert battery as in direction shown in diagram.
- d. Replace battery seal, cover and locking ring in reverse order.
- e. Tighten the set screw with the allen wrench.

#### 'Start up' mode:

1. The Flush Valve, automatically enters 'start up' mode whenever new batteries are put in.

'Start up' mode is a 3 minutes period of time when the Valve Sensor light will pulsate when something enters in its Focal range. The 'Start up' time is useful for all adjustments described in the next paragraph.

- 2. One can activate the 'start up' mode anytime while in normal mode. There are two ways to do that:
  - a) Remove the batteries, wait for 2minutes and replace the batteries. It enters 'start up' mode.
  - b) Remove the batteries, short-circuit the circuit board for one second, and replace the battery.

3. When the warning light is on, replace the battery with a new one. If the old battery with low voltage is put back in, the Valve will enter 'shut down-mode' (not enough voltage to enter 'start up' mode).

# <u>Adjustments</u> (1) <u>Adjust sensing distance</u>


Remove the Locking Ring and the Cover. Use a slot-head screwdriver to adjust the variable resistor in the hole. Turn counterclockwise to shorten sensing distance, or clockwise to lengthen it. The factory setting is 8"-10" using a Kodak gray card. DO NOT make adjustment unless necessary.


#### (2) Adjust sensing angle

The entire Electronic Module could be rotated (by loosening the 2 side screws) if you desire the Infrared Beam to sense at a different angle than  $90^{\circ}$  normal to the wall.

#### (3) Adjust flushing time


| SW3 | SW2 | SW1 | FLUSH TIME |
|-----|-----|-----|------------|
| OFF | OFF | OFF | 3.0 SEC    |
| ON  | OFF | OFF | 2.5 SEC    |
| OFF | ON  | OFF | 2.0 SEC    |
| ON  | ON  | OFF | 1.5 SEC    |
| OFF | OFF | ON  | 1.25SEC    |
| ON  | OFF | ON  | 1.0 SEC    |
| OFF | ON  | ON  | 0.7SEC     |
| ON  | ON  | ON  | 0.5 SEC    |





Factory setting is 1.0sec. Change the 3 switches (SW1, SW2, SW3) shown in the picture on left, referring to the above chart to adjust the appropriate flush time and obtain an optimum flushing effect.

#### (4) Adjust water volume




- a. Unscrew Stop Cap.
- b. Adjust Control Stop Valve water outflow volume with screwdriver. (Adjust toilet water flow.)
- c. Tighten control stop cap clockwise.

#### SPEAKMAN

PO Box 191 Wilmington, DE 19899 Phone: 800-537-2107 Fax: 800-977-2747 Visit us on the web at www.speakmancompany.com

#### (5) Clean filter screen



Poor water quality will result in obstructed and reduced flow. Turn off water supply (use a slot-head screwdriver to turn the flow adjust shaft clockwise). Remove the filter unit with the screwdriver, clean it and replace it in reverse order.


| Trouble                      | Possible cause                      | Troubleshooting                      |
|------------------------------|-------------------------------------|--------------------------------------|
| Red lamp flashing            | 1. Weak battery                     | Replace battery (CR-P2 Lithium)      |
| No<br>flushing               | 1. Dirty sensor window              | Wipe sensor window with tissue paper |
| (Red lamp does not light on  | 2. Sensing distance too long        | Shorten sensing distance             |
| during sensing process)      | 3. Control circuit failure          | Replace control circuit              |
| No<br>flushing               | 1. Water faucet not turned on       | Check water supply                   |
| (Red lamp flashes on and off | 2. Solenoid terminal loosened       | Re-connect solenoid terminal         |
| during sensing process)      | 3. Solenoid failure                 | Replace solenoid                     |
|                              | 4. Control circuit failure          | Replace control circuit              |
| Water keeps running          | 1. Solenoid diaphragm<br>obstructed | Clean solenoid diaphragm             |
|                              | 2. Manual knob defective            | Replace manual knob                  |
|                              | 3. Control circuit failure          | Replace control circuit              |
| Water flow too weak          | 1. Water inflow too weak            | Adjust valve to increase water flow  |
|                              | 2. Filter valve obstructed          | Clean filter valve                   |

#### Troubleshooting

\* Make sure to locate the trouble, and refer to the list for troubleshooting.


\* Make sure to use CR-P2 Lithium battery.

#### **RPG (Repair Parts Groups) List for Flush Valve**



SPEAKMAN PO Box 191 Wilmington, DE 19899 Phone: 800-537-2107 Fax: 800-977-2747 Visit us on the web at www.speakmancompany.com

#### **RPG (Repair Parts Groups) List for Trims**



#### **REPAIR PARTS LISTING**

| Part or Group      | Description                                          | <b>Refer to Packing List</b> |
|--------------------|------------------------------------------------------|------------------------------|
| SUV-2000           | Urinal Valve complete without Trim                   | <u> </u>                     |
| SWCV-2000          | Water Closet Valve complete without Trim             |                              |
| RPG 02-0007        | 1" Sweat Solder Kit                                  |                              |
| RPG 02-0008        | 3/4" Sweat Solder Kit                                |                              |
|                    |                                                      |                              |
| RPG 24-0121        | 1" Control Stop Assembly                             |                              |
| RPG 24-0122        | 3/4" Control Stop Assembly                           |                              |
| 24-0302            | Stop Cap                                             |                              |
|                    |                                                      |                              |
| RPG 21-0089        | Control Stop Repair Kit                              |                              |
|                    |                                                      |                              |
| RPG 02-0009        | 1-1/2"Vacuum Breaker Tube 9"lg                       |                              |
| RPG 02-0010        | 3/4"Vacuum Breaker Tube 9"lg                         |                              |
| <b>BBC 02 0012</b> | 1 1/2"Woonum Dreaker Take 26"12                      |                              |
| RPG 02-0012        | 1-1/2"Vacuum Breaker Tube 26"lg                      |                              |
| RPG 02-0013        | 3/4"Vacuum Breaker Tube 26"lg                        |                              |
| RPG 21-0088        | Vacuum Breaker Repair Kit                            |                              |
| RPG 02-0015        | 1-1/2" Spud Coupling Kit                             |                              |
| RPG 02-0016        | 3/4" Spud Coupling Kit                               |                              |
| RI G 02 0010       |                                                      |                              |
| RPG 11-0046        | Push Button                                          |                              |
| RPG 11-0047        | Vandal Resistant Button                              |                              |
|                    |                                                      |                              |
| RPG76-0144         | One 6-volt lithium -Panasonic CR-P2 -or Duracell 223 |                              |
| RPG76-0145         | Solenoid Valve 6 VDC                                 |                              |
| RPG 76-0061        | Electronics assembly for WC Flush Valve              |                              |
| RPG 76-0062        | Electronics assembly for Urinal Valve                |                              |
|                    |                                                      |                              |
| RPG 02-0018        | Locking Ring and with screw                          |                              |
| 10-0330            | Cover                                                |                              |
| 10-0331            | Rubber Gasket                                        |                              |
| RPG 05-0826        | Diaphragm Repair Kit                                 |                              |
| RPG 05-0827        | Renewable Seat Kit                                   |                              |
| 49-0186            | Tailpiece O-Ring         3/32 x 1-3/16 x 1-3/8       |                              |
|                    |                                                      |                              |
| 21-0192            | Filter                                               |                              |
|                    |                                                      |                              |
| 24-0303            | Tool for Renewable Seat change                       |                              |



# Speakman Flush Valve Specification (August 2007)

| Type:<br>Product Certification: | Battery operated exposed top mount unit<br>Speakman flush valve is certified by IAPMO to be in compliance with<br>ASSE 1037 1990, CSA B125.03-05 and applicable sections of ASME<br>A112.19.2-2003                                                           |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Retrofit:                       | Valve rough-in adaptable to existing Sloan stops and tailpieces                                                                                                                                                                                              |
| Installation:                   | Adaptable to both right and left hand stop installations.                                                                                                                                                                                                    |
| <b>Operating Pressures:</b>     | Operates in a normal manner between 20 - 80 psi<br>Functional between 15 – 100 psi                                                                                                                                                                           |
| GPF Water Closet:               | Factory Setting for 1.6 GPF                                                                                                                                                                                                                                  |
| GPF Urinal:                     | Timing adjustments to accommodate installed 3.5 GPF models<br>Factory setting for 1.0 GPF                                                                                                                                                                    |
| orr orman.                      | Timing adjustments to accommodate installed 1.5 GPF models                                                                                                                                                                                                   |
| Timing Adjustments:             | Flush time settings of 1.5, 2.0, 2.5, 3.0, 3.5, 4.0, 6.0, 8.0 seconds for WC.<br>Factory setting is 2.5 seconds for the WC<br>Flush time settings of 0.5, 0.7, 1.0, 1.25, 1.5, 2.0, 2.5, 3.5 seconds for U.<br>Factory setting is 1.0 seconds for the Urinal |
| Batteries:<br>Battery Life:     | One 6-volt lithium. Panasonic CR-P2 or Duracell 223<br>Battery life @ 100 flushes per day is approximately 3 years                                                                                                                                           |

**SPEAKMAN**<sup>®</sup>

92-2842-R5

PO Box 191 Wilmington, DE 19899 Phone: 800-537-2107 Fax: 800-977-2747 Visit us on the web at www.speakmancompany.com

| Battery Warning Light:<br>Battery Change: | Warning light to be activated 10 days or 1,000 activations, whichever<br>comes first, prior to programmed shutdown<br>Warning light to continue flashing after programmed shutdown until battery<br>change or power loss<br>Batteries can be changed without shutting off water supply |  |
|-------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
| W/C Sensor Range:<br>Urinal Sensor Range: | 10" - 24" (25 cm – 60 cm)<br>Factory setting to be 14" - 16" (35 cm – 40cm) Based on grey card reading<br>6" – 20" (15 cm – 50 cm)                                                                                                                                                     |  |
| Ormai Schsor Kange.                       | Factory setting to be $8" - 10"$ (20cm - 25cm) Based on grey card reading                                                                                                                                                                                                              |  |
| Focal Distance Adjustment                 | t: Sensor range is adjustable by a potentiometer<br>Adjustments can be made while the valve is operational                                                                                                                                                                             |  |
| Sensor Beam Adjustment:                   | Sensor beam can be pivoted for horizontal adjustment<br>Sensor beam can be adjusted while the valve is operational                                                                                                                                                                     |  |
| Sensor Direction:                         | WC sensor beam is angled 15 degrees up<br>Urinal sensor beam is angled 15 degrees down                                                                                                                                                                                                 |  |
| Start-Up Mode:                            | Electronics programming includes a start-up feature whereby the valve can<br>be adjusted for the first three minutes with flashing light indicator<br>See IOM for detailed discussion of start-up mode operation                                                                       |  |
| Settings Memory:                          | Programmed settings are retained in memory in case of battery draw-down and/or battery change                                                                                                                                                                                          |  |
| Min. Detection Time:<br>Flush Delay:      | 7 seconds after initial detection<br>Flush delay for WC is 3 seconds<br>Flush delay for urinal is 1 second                                                                                                                                                                             |  |
| Auto Flush:                               | Every 24 hours beginning 24 hours after last flush                                                                                                                                                                                                                                     |  |
| Water Proof:                              | Design incorporates redundant sealing mechanisms to keep unit water proof                                                                                                                                                                                                              |  |
| Seating Surface:                          | Valve has a renewable seat                                                                                                                                                                                                                                                             |  |
| Metal Cover:                              | Standard                                                                                                                                                                                                                                                                               |  |
| Maintenance Override:                     | Non electronic maintenance override<br>Override available in push button or with vandal resistant cover                                                                                                                                                                                |  |
| Adjustable Centers:                       | Stop adjustment 4 1/4" - 5 1/4"                                                                                                                                                                                                                                                        |  |
| Maintenance:<br>Warranty:                 | Designed for easy access, maintenance and replacement of components<br>Three years, excluding battery                                                                                                                                                                                  |  |

92-2842-R5

**SPEAKMAN**<sup>®</sup> PO Box 191 Wilmington, DE 19899 Phone: 800-537-2107 Fax: 800-977-2747 Visit us on the web at www.speakmancompany.com